

How to Install the BoreHead HDPE Pipe Pulling Tool

- 1) Dry fit the MJ Adapter into the BoreHead. This will insure the two will mate up properly. BoreHead recommends the use of the BoreHead MJ Adapters. [See Picture 1](#)



Picture 1



Picture 2



Picture 3



Picture 4



Picture 5



Picture 6

- 2) With a sand block make sure the connecting surfaces of the BoreHead are smooth and contaminate free.
- 3) Inspect the bolts, nuts and washers to make sure they are in good condition.
- 4) Fuse on the proper MJ Adapter onto the pipe run above ground. [See Picture 2](#)
- 5) Place MJ Adapter and Pipe into the BoreHead Shell. Make sure the MJ Adapter is completely seated inside the BoreHead Shell. [Picture 3](#)
- 6) Place the opposite BoreHead shell onto the top of the MJ Adapter and Pipe. [Picture 4](#)
- 7) Using the supplied 8) Nuts, 8) Bolts, and 16) Washers, tighten them snug. DO NOT OVER TIGHTEN [Picture 5](#)
- 8) YOU ARE READY TO PULL THE MJ ADAPTER AND PIPE INTO PLACE. [Picture 6](#)